

ETC Keyboard Shortcuts

Eos Family Consoles

Hotkeys

The following is a list of common Eos functions and their associated Windows keyboard shortcuts.

Console Function	Windows Keyboard Shortcut
Shortcut List	Alt /
	?
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
. (decimal)	. (decimal)
- (minus)	- (minus)
+ (plus)	=
	+
+%	Shift =
	Control Alt =
-%	Shift -
	Control Alt -
/	/
A3D Camera Up	Up Arrow
A3D Camera Up (Edit Mode)	W
A3D Camera Forwards	Shift Up Arrow
A3D Camera Forwards (Edit Mode)	Shift W
A3D Camera Left	Left Arrow
A3D Camera Left (Edit Mode)	A
A3D Camera Down	Down Arrow
A3D Camera Down (Edit Mode)	S
A3D Camera Backwards	Shift Down Arrow
A3D Camera Backwards (Edit Mode)	Shift S
A3D Camera Right	Right Arrow
A3D Camera Right (Edit Mode)	D
About	Y
Address / Dimmer	Alt A
All NPs	Control N
Assert	Control W
Assert (Playback)	Control Alt A



ETC Keyboard Shortcuts

Eos Family v3.1.0

At	A
	@
	*
Back (ECU)	Escape
Beam Filter	Control B
Beam Palette	Alt B
Blind	F2
	Control 2
Block	B
Capture	Control Alt P
Clear	Backspace
Clear Command Line	Shift Backspace
	Control Alt Backspace
Clear Label	Control Backspace
Color Filter	Control C
Color Palette	Alt C
Color Path	Control Alt W
Copy To	C
Cue	Q
Cue Only / Track	X
Data	Control D
Data Mode	Control Shift D
Delay	D
Delete	Delete
Delete (macOS)	Fn Delete
Displays	F9
	Control 9
Effect	Alt E
Effects Softkeys	Alt Shift E
Encoder Display (Gio)	Control Alt \
Encoder Page Color ^	Control Alt [
Encoder Pager Focus ^	Control Alt ,
Encoder Page Form ^	Control Alt ;
Encoder Page Image ^	Control Alt]
Encoder Page Intensity ^	Alt .
Encoder Page Shutter ^	Alt ,
Enter	Enter
Escape	Escape
Expand	F5
	Control 5
Fader Page	V
Fan	W
FlexiChannel	F3
	Control 3

ETC Keyboard Shortcuts

Eos Family v3.1.0

Focus Filter	Control F
Focus Palette	Alt F
Follow / Hang	Shift D
	Control Alt D
Format	F4
	Control 4
(Scroller) Frame	Control Alt C
Freeze	Control Alt F
Full	F
Go	Spacebar
Go To Cue	Control G
Go To Cue Zero	Control Alt G
Group	G
Help	Alt /
Highlight	\
	Control Alt H
Home	Home
	Control H
Home (macOS)	Fn Left Arrow
Intensity Block	Shift B
	Control Alt B
Intensity Filter	Control I
Intensity Palette	Alt I
Label / Note	L
Last	Page Up
	Control ,
Last (macOS)	Fn Up Arrow
Learn	Alt L
Level	Control V
Live	F1
	Control 1
Load	Control Alt L
Macro	M
Macro 801*	Control Alt 1
Macro 802*	Control Alt 2
Macro 803*	Control Alt 3
Macro 804*	Control Alt 4
Macro 805*	Control Alt 5
Macro 806*	Control Alt 6
Macro 807*	Control Alt 7
Macro 808*	Control Alt 8
Macro 809*	Control Alt 9
Macro 810*	Control Alt 0
Magic Sheet	Alt M

ETC Keyboard Shortcuts

Eos Family v3.1.0

Manual Override	Control Alt M
	Control Alt N
Mark	K
	Control Alt K
Mirror Start	Alt F1
Mirror Stop	Alt F2
ML Controls	F7
	Control 7
More Softkeys (More SK)	Alt 7
Next	Page Down
	Control
Next (macOS)	Fn Down Arrow
Off	Control Alt O
Offset	Control O
Out	O
Page Left	Left Arrow
Page Right	Right Arrow
Page Up	Up Arrow
Page Down	Down Arrow
Parameters (Display)	Control D
Park	Alt K
Part	P
Patch	;
Pixel Map	Alt X
Preset	Alt P
Query	Control Q
Rate	Control Alt R
Recall From	E
Record	R
RecordOnly	Control R
Release	Control Alt S
Rem Dim	H
Scroll Lock	Control 6
Select	Control Enter
Select (ECU)	Return
Select Active	Control A
Select Last	Control L
Select Manual	Control M
Setup	Alt S
Shift	Z
Snapshot	Control S
Sneak	N
Softkey 1	Alt 1
Softkey 2	Alt 2

ETC Keyboard Shortcuts

Eos Family v3.1.0

Softkey 3	Alt 3
Softkey 4	Alt 4
Softkey 5	Alt 5
Softkey 6	Alt 6
Spacebar Disable	Alt G
Staging Mode	F6
Stop / Back	Control Spacebar
	Control Alt Q
Stop Effect	Shift Alt E
Submaster	S
Tab	Tab
Time	I
Time (Displays)	Control Alt I
Timing Disable	Control Alt T
Toggle Hotkeys	F8
	Control 8
Trace	J
Thru	T
Undo	Control X
Update	U
Virtual Keyboard	Control K
Workspace] or [
Zoom selected display	Left Mouse Button + Scroll Wheel
*Some Shortcut Key combinations are not available on all physical keyboard layouts.	
^Alternatively use Encoder Display + category to change the encoder pages.	



Note: To enable Eos functions on macOS Function keys:

1. Navigate to **System Preferences > Keyboard**
2. Enable the "Use all F1, F2, etc... keys as standard function keys" setting.



Note: Some international keyboards require "Use Shift Key As Eos Shift" to be disabled in **Setup > Device > Face Panel > Input Devices**. Use Z as shift to access shortcut functions in these cases.
